Gluing two melamine surfaces together

Canonical: https://www.selleys.com.au/ask-an-expert/adhesives/what-is-the-best-adhesive-to-glue-two-pieces-of-melamine-together/

Details:

What is the best adhesive to glue two pieces of melamine together?

We are candid about this one: gluing melamine to melamine is difficult , and adhesive alone is not the recommendation. We suggest using some form of manual fixing — screws or dowelling — to support and strengthen the joint, with a polyurethane glue doing the bonding. In our range the polyurethane woodworking glue is Aquadhere Durabond , described as super durable and high strength.

There is one preparation step that does more for the result than the glue choice: sand the melamine surfaces first. That is our advice, and it is the whole problem in one line.

Why melamine resists glue

Melamine's surface is a hard, sealed decorative laminate. It is designed to shed spills, resist scratching and stay clean — which is precisely the set of properties that stops an adhesive keying into it. There is nothing for the glue to grip and nothing for it to soak into. Sanding gives it a mechanical key, which is why we name it as the step that assists adhesion.

The second issue is what is underneath. Melamine-faced board is usually particleboard or MDF, and the joint between two panels is typically a butt joint into board edge — which is weak in the material itself, before any adhesive is considered. That is why We recommend screws or dowels: the fixings carry the load and the glue holds the assembly together.

Limitations

Not recommended for structural applications. This is the technical backing for our advice to add screws or dowelling.

Not suitable for below-waterline applications or continuous submersion. It is waterproof, but not for permanent water immersion.

Not recommended for polyethylene or polypropylene plastics. Most other plastics can be bonded after testing.

Requires atmospheric moisture to cure , so its use may be restricted in very dry conditions, and it cannot be applied below 5°C.

Contamination from iron and steel — nails, screws, steel tools — can cause brown or black staining, and timber tannins can discolour it. On a white melamine panel that shows.

Safety: the glue that does this job is the one to ventilate for

Aquadhere Durabond is classified Danger under Safe Work Australia GHS 7, and it is by a wide margin the most heavily classified adhesive in the Aquadhere range:

H334 — may cause allergy or asthma symptoms or breathing difficulties if inhaled. Respiratory sensitisation, Category 1A.

H351 — suspected of causing cancer (Category 2, not the stronger H350).

H373 — may cause damage to organs through prolonged or repeated exposure.

H332 harmful if inhaled; H335 respiratory irritation; H317 skin sensitisation (1A); H315 skin irritation; H319 serious eye irritation.

Aquadhere Exterior , mentioned above, is not classified as hazardous at all.

The clamping point matters more than usual

Foaming is an asset and a liability at once. On high humidity and damp surfaces, increased foaming can result in a weakened joint. The counter is pressure: tighter clamping reduces foaming and improves bond quality, and weighting works as an alternative where clamps will not reach.

So the sequence for melamine is: sand, apply, clamp firmly for about four hours, and leave it 24 hours before you load it. On a panel joint the screws or dowels are doing double duty here — they hold the assembly in register while the glue expands against itself.

How to glue melamine to melamine

Sand both melamine faces to be bonded. This is the step that makes the adhesion possible.

Dust off the sanding residue and check the surfaces are clean.

Drill and dry-fit the screws or dowels first, so the assembly is registered before glue goes anywhere near it.

Because Durabond is moisture-curing, wipe very dry or porous surfaces with a damp cloth for one minute before bonding. Sanded melamine edge exposes the board core, which is porous.

Apply the glue, assemble, and clamp firmly — tighter is better — for about four hours until initial set.

Once cured, trim or sand off the foamed excess. Do not try to wipe it away while it is expanding; you will smear it into the surface.

Allow 24 hours for maximum strength before loading the joint.

What the polyurethane glue does

Aquadhere Durabond is a solvent-free, moisture-curing polyurethane. Its defining behaviour is that it foams and expands as it cures . That expansion is what lets it fill and bridge a joint rather than sitting as a thin, brittle film, and it is why the excess has to be dealt with — as our advice says, it is best to trim or sand any excess off once it has cured.

Property	Typical result
Technology	Solvent-free, moisture-curing polyurethane
Colour	Amber, drying to a yellow opaque finish
Clamp time	Firm clamping for approximately 4 hours to initial set
Maximum strength	24 hours, depending on humidity and material porosity
Heat resistance	Up to 140°C

Finishing	Sandable, paintable and stainable after curing

Figures are indicative data only and are not intended for the preparation of specifications.

Note on colour: the answer on this page describes the glue as a treacle or honey colour drying to white. The product's technical data gives the colour as amber, drying to a yellow opaque finish. Either way, the glue line is visible on a white melamine panel, which is a further reason to trim and sand the excess rather than leaving squeeze-out on show.

What follows from that for a melamine panel

Five of those eight classifications concern the respiratory tract, and this job has three separate airborne moments. You sand the melamine faces first. Then the adhesive foams and cures while clamped. Then you sand or trim the cured excess. The classifications above belong to the uncured adhesive, so the middle stage is the one they govern — and it is the stage people walk away from. Clamping for four hours and leaving it 24 hours means the panel is off-gassing in whatever room you left it in, usually a closed garage or a spare bedroom. Ventilate for the cure, not just for the minute you spread glue.

H334 is permanent, and it is acquired quietly. Respiratory sensitisation means the immune system learns to react to the material. Once that happens the change is generally permanent, and afterwards an exposure far smaller than the one that caused it can provoke wheeze, chest tightness or an asthma attack. It builds from repeated exposure at levels that feel like nothing at the time. H373 and H351 work the same way: neither describes one careful joint in an open garage; both describe an accumulation.

The instruction not to wipe the squeeze-out is also the right instruction for your skin. The page gives it for finish reasons — wiping expanding polyurethane smears it. H317 at Category 1A is the other reason. Skin sensitisation is permanent once acquired and is built from repeated casual contact, which is what wiping foaming glue off a white panel with a rag amounts to. Let it cure, then trim it. Wear nitrile gloves while applying, and safety glasses for both sanding stages and for H319.

Aquadhere Exterior carries no classification, but the page is explicit that a PVA is not the answer on a sealed melamine face. The control here is ventilation and gloves, not a substitution.

Poisons Information Centre — 131 126 in Australia, 0800 764 766 in New Zealand.

Related questions and guides

Related pages, and others in this section:

Chipboard to Melamine Adhesive

Best Adhesive for Fixing Your Rubber Shoe Sole

Best Adhesive To Bond Aluminium to MDF

Best Glue for Australian Hardwood

Best Glue for Leather-to-Leather Bonding

Brass to Sandstone Adhesive

Chipboard Adhesive

Choosing a clear adhesive for glass

Browse from here

Where this page sits:

Selleys Ask an Expert: Tips for Using Adhesives

Ask an Expert

Adhesives, Fillers, Sealants & More

DIY Living Room Project Ideas and Guides

All Products

Will sanding two melamine faces make Durabond suitable?

Our earlier answer suggested sanding to assist adhesion, but the technical sheet still requires close-fitting surfaces with at least one porous face. Confirm the exact joint with our team before bonding. Keep mechanical fixings such as the specified screws or dowels.

Will the cured glue be white?

Our earlier answer said white, while the 29 May 2020 technical sheet says amber drying yellow opaque. Confirm your exact pack’s appearance before a colour-critical repair.

Does foaming make it suitable for any loose joint?

No. Foaming does not remove the close-fit and porous-surface requirements. Excess moisture can increase foaming and weaken a bond; confirm the repair before applying the glue.

What is the best adhesive to glue two pieces of melamine together?

We are candid about this one: gluing melamine to melamine is difficult , and adhesive alone is not the recommendation. We suggest using some form of manual fixing — screws or dowelling — to support and strengthen the joint, with a polyurethane glue doing the bonding.

Why melamine resists glue?

Melamine's surface is a hard, sealed decorative laminate. It is designed to shed spills, resist scratching and stay clean — which is precisely the set of properties that stops an adhesive keying into it. There is nothing for the glue to grip and nothing for it to soak into.

What are the limitations?

Not recommended for structural applications. This is the technical backing for our advice to add screws or dowelling; Not suitable for below-waterline applications or continuous submersion. It is waterproof, but not for permanent water immersion; Not recommended for polyethylene or polypropylene plastics. Most other plastics can be bonded after testing; Requires atmospheric moisture to cure , so its use may be restricted in very dry conditions, and it cannot be applied below 5°C; Contamination from iron and steel — nails, screws, steel tools — can cause brown or black staining, and timber tannins can discolour it. On a white melamine panel that shows.

What should I know about safety?

Aquadhere Durabond is classified Danger under Safe Work Australia GHS 7, and it is by a wide margin the most heavily classified adhesive in the Aquadhere range: Aquadhere Exterior , mentioned above, is not classified as hazardous at all.

What is the clamping point matters more than usual?

Foaming is an asset and a liability at once. On high humidity and damp surfaces, increased foaming can result in a weakened joint. The counter is pressure: tighter clamping reduces foaming and improves bond quality, and weighting works as an alternative where clamps will not reach.